


Aiguilles

12 dans une boîte



1/2 cercle



chas fermé
GN



chas à
ressort GF



chas fermé
GRN




chas à
ressort GRF



90 mm N°00		Z 751	Z 850
80 mm N°1	Z 702	Z 752	Z 851
70 mm N°2	Z 703	Z 753	Z 853
65 mm N°3	Z 704		
60 mm N°4		Z 755	Z 855
55 mm N°6	Z 706	Z 756	Z 806 Z 856
50 mm N°7		Z 758	Z 807 Z 858
48 mm			Z 840
45 mm N°8	Z 708	Z 759	Z 808 Z 859
40 mm N°9	Z 710	Z 760	Z 810 Z 860
35 mm N°10	Z 711	Z 761	Z 811 Z 861
30 mm N°12	Z 712	Z 762	Z 812 Z 862
25 mm N°13	Z 713	Z 763	Z 813 Z 863
20 mm N°15	Z 714	Z 764	Z 814 Z 864
16 mm N°16		Z 766	Z 866

AIGUILLE CORDEE (SKI)



80 mm N°1		Z 202
70 mm N°2		Z 203
65 mm N°3		Z 204
60 mm N°4		Z 205
57 mm N°5		Z 201
55 mm N°6		Z 206
50 mm N°7		Z 207
45 mm N°8		Z 208
40 mm N°9	Z 260	
35 mm N°10	Z 261	
30 mm N°12	Z 262	
25 mm N°13	Z 263	
20 mm N°15	Z 264	
16 mm N°16	Z 266	
12 mm N°20	Z 268	



3/8 cercle




	 chas fermé BN		 chas à ressort BRN		 chas fermé BRT
130 mm N°6-0	Z 495		Z 595		
110 mm N°4-0			Z 599		
100 mm N°000	Z 500	Z 550		Z 650	
90 mm N°00	Z 501	Z 551	Z 601	Z 651	Z 301
90 mm LIGHT N°00	Z 502		Z 602		
85 mm N°0			Z 590		
80 mm N°1	Z 503	Z 552	Z 591		Z 303
70 mm N°2	Z 504	Z 553	Z 603	Z 653	
70 mm LIGHT N°2	Z 504L				
65 mm N°3			Z 604		
60 mm N°4	Z 505	Z 555		Z 655	
57 mm N°5	Z 506		Z 605		
55 mm N°6		Z 556		Z 656	
50 mm N°7		Z 557	Z 607	Z 657	
45 mm N°8	Z 508	Z 558	Z 608	Z 658	
40 mm N°9	Z 510	Z 560	Z 610	Z 660	
35 mm N°10	Z 511	Z 561	Z 611	Z 661	
32 mm N°11		Z 570		Z 670	
30 mm N°12	Z 512	Z 562	Z 612	Z 662	
25 mm N°13	Z 513	Z 563	Z 613	Z 663	
22 mm N°14		Z 571		Z 671	
20 mm N°15	Z 514	Z 564	Z 614	Z 664	
16 mm N°16	Z 516	Z 566		Z 666	
14 mm N°17		Z 567		Z 667	
12 mm N°20		Z 568			

DROITE



chas fermé
GSN

chas à
ressort
GSF



75 mm N° 1		Z 904
60 mm N° 4	Z 903	Z 913
45 mm N° 8	Z 902	
40 mm N° 9		Z 912
35 mm N° 10		Z 911